

Classical Signal Theory

Lesson 1

Continuous Signals

- A continuous-time signal is a complex function of a real variable that has, as a codomain, the set of complex numbers.

$$s(t), t \in \mathbb{R}$$


- Real signals:

$$s(t) = s^*(t)$$

Periodic Signals



- Periodic signals: $s(t + T_p) = s(t)$,
where the condition is satisfied for T_p and for kT_p
where k is an integer.
- Periodic repetition formulation:

$$s(t) = \sum_{n=-\infty}^{+\infty} u(t - nT_p) \triangleq \text{rep}_{T_p} u(t),$$



Continuous Signals

- A signal is *even* if: $s(-t) = s(t)$,
- A signal is *odd* if: $s(-t) = -s(t)$




- An arbitrary signal can be always decomposed into the sum of an *even* component $s_e(t)$ and an *odd* component $s_o(t)$

- $$s(t) = s_e(t) + s_o(t),$$

$$s_e(t) = \frac{1}{2}[s(t) + s(-t)], \quad s_o(t) = \frac{1}{2}[s(t) - s(-t)].$$

Continuous Signals

- Causal signal: $s(t) = 0$ for $t < 0$.
- Time shift: $s_{t_0}(t) = s(t - t_0)$



- Area: $\text{area}(s) = \int_{-\infty}^{+\infty} s(t) dt.$

- Mean value: $m_s = \lim_{T \rightarrow \infty} \frac{1}{2T} \int_{-T}^T s(t) dt$

Continuous Signals

- Energy: $E_s = \int_{-\infty}^{+\infty} |s(t)|^2 dt,$

- Specific power: $P_s = \lim_{T \rightarrow \infty} \frac{1}{2T} \int_{-T}^T |s(t)|^2 dt.$



Definitions over a period

- Mean value over a period:

$$m_s(T_p) = \frac{1}{T_p} \int_{t_0}^{t_0+T_p} s(t) dt.$$

- Energy over a period:

$$E_s(T_p) = \int_{t_0}^{t_0+T_p} |s(t)|^2 dt.$$

- Power over a period:

$$P_s(T_p) = \frac{1}{T_p} E_s(T_p) = \frac{1}{T_p} \int_{t_0}^{t_0+T_p} |s(t)|^2 dt.$$

Example of a signal

- A sinusoidal signal:

$$s(t) = A_0 \cos(\omega_0 t + \phi_0) = A_0 \cos(2\pi f_0 t + \phi_0) = A_0 \cos\left(2\pi \frac{t}{T_0} + \phi_0\right)$$

- It can be written as: $s(t) = A_0 \cos \phi_0 \cos \omega_0 t - A_0 \sin \phi_0 \sin \omega_0 t$,
- Using Euler's formulas:

$$\cos x = \frac{e^{ix} + e^{-ix}}{2}, \quad \sin x = \frac{e^{ix} - e^{-ix}}{2i},$$

- It becomes:

$$s(t) = A_0 \cos(\omega_0 t + \phi_0) = \frac{1}{2} A_0 e^{i(\omega_0 t + \phi_0)} + \frac{1}{2} A_0 e^{-i(\omega_0 t + \phi_0)}.$$

- it can be written as the real part of an exponential signal:

$$s(t) = \Re A e^{i\omega_0 t}, \quad A = A_0 e^{i\phi_0}.$$



Some useful signals

- The step signal: $s(t) = A_0 1(t - t_0)$,
- Where the unit step function is:

$$1(x) = \begin{cases} 0, & \text{for } x < 0, \\ 1, & \text{for } x > 0. \end{cases} \quad 1(0) = \frac{1}{2}$$

- The rectangular function:

$$\text{rect}(x) = \begin{cases} 1, & \text{for } |x| < \frac{1}{2}, \\ 0, & \text{for } |x| > \frac{1}{2}, \end{cases}$$



Some useful signals

- A triangular pulse: $\text{triang}(x) = \begin{cases} 1 - |x| & \text{for } |x| < 1; \\ 0 & \text{for } |x| > 1. \end{cases}$

- The impulse: $\delta(t)$ is assumed to vanish for $t \neq 0$

$$\int_{-\infty}^{\infty} \delta(t) dt = 1, \quad \int_{-\infty}^{\infty} \delta(t) s(t) dt = s(0).$$

- Can be seen as a limit as D tends to zero.

$$r_D(t) = \frac{1}{D} \text{rect}\left(\frac{t}{D}\right), \quad \delta(t) = \lim_{D \rightarrow 0} r_D(t).$$


$$\lim_{D \rightarrow 0} \int_{-\infty}^{\infty} r_D(t) s(t) dt = \lim_{D \rightarrow 0} \frac{1}{D} \int_{-D/2}^{D/2} s(t) dt = s(0),$$

On the impulse

$$\int_{-\infty}^{\infty} s(t)\delta(t - t_0) dt = \int_{-\infty}^{\infty} s(t + t_0)\delta(t) dt = s(t_0).$$

$$\int_{-\infty}^{\infty} \delta(-t)s(t) dt = \int_{-\infty}^{\infty} \delta(t)s(-t) dt = s(0) = \int_{-\infty}^{\infty} \delta(t)s(t) dt,$$


$$s(t) = \int_{-\infty}^{+\infty} s(u)\delta(t - u) du.$$



The sinc pulses

$$A_0 \operatorname{sinc}\left(\frac{t - t_0}{T}\right), \quad \operatorname{sinc}(x) = \frac{\sin \pi x}{\pi x}$$

- The periodic sinc $\operatorname{sinc}_N(x) = \frac{1}{N} \frac{\sin \pi x}{\sin \frac{\pi}{N} x}$,



Convolution

- Given two continuous signals $x(t)$ and $y(t)$, their convolution defines a new signal:


$$s(t) = \int_{-\infty}^{+\infty} x(u)y(t - u) du.$$

- This is concisely denoted by: $s = x * y$
- If we define: $z_t(u) = z(u - t) = y(-(u - t)) = y(t - u)$,

The convolution becomes: $s(t) = \int_{-\infty}^{+\infty} x(u)z_t(u) du.$

Convolution

In conclusion, to evaluate the convolution *at the chosen time t* , we multiply $x(u)$ by $z_t(u)$ and integrate the product.



Convolution

- In this interpretation, we hold the first signal while inverting and shifting the second.
- However, with a change of variable $v = t - u$, we obtain the alternative form


$$s(t) = \int_{-\infty}^{+\infty} x(t - u)y(u) du,$$

in which we hold the second signal and manipulate the first to reach the same result.

Convolution example

- We want to evaluate the convolution of the rectangular pulses

$$x(t) = A_1 \operatorname{rect}\left(\frac{t}{4D}\right), \quad y(t) = A_2 \operatorname{rect}\left(\frac{t}{2D}\right).$$






$$s(t) = \begin{cases} 0, & \text{if } t < -3D \text{ or } t > 3D; \\ A_1 A_2 (t + 3D), & \text{if } -3D < t < -D; \\ A_1 A_2 2D, & \text{if } -D < t < D; \\ A_1 A_2 (3D - t), & \text{if } D < t < 3D. \end{cases}$$

Convolution example

- We evaluate the convolution of the signals

$$x(t) = A_0 \operatorname{rect}\left(\frac{t}{2D}\right), \quad y(t) = u(t).$$



$$s(t) = \begin{cases} 0, & \text{if } t < -D; \\ A_0(t + D), & \text{if } -D < t < D; \\ A_0 2D, & \text{if } t > D, \end{cases}$$

Convolution of a periodic signal

- The convolution of two periodic signals $x(t)$ and $y(t)$ with the **same period** T_p is then defined as:

$$x * y(t) \triangleq \int_{t_0}^{t_0+T_p} x(u)y(t-u) du.$$

- where the integral is over an arbitrary period (t_0, t_0+T_p) . This form is sometimes called the *cyclic convolution* and then the previous form the *acyclic convolution*.

The Fourier Series

- We recall that in 1822 Joseph Fourier proved that an arbitrary (real) function of a real variable $s(t)$, $t \in \mathbb{R}$, having period T_p , can be expressed as the sum of a series of sine and cosine functions with frequencies multiple of the *fundamental frequency* $F = 1/T_p$, namely

$$s(t) = A_0 + \sum_{k=1}^{\infty} [A_k \cos 2\pi k F t + B_k \sin 2\pi k F t].$$

The exponential form

- A continuous signal $s(t)$, $t \in \mathbb{R}$, with period T_p , can be represented by the *Fourier series*

$$s(t) = \sum_{n=-\infty}^{\infty} S_n e^{i2\pi n F t}, \quad F = \frac{1}{T_p},$$

- Where:

$$S_n = \frac{1}{T_p} \int_{t_0}^{t_0+T_p} s(t) e^{-i2\pi n F t} dt, \quad n \in \mathbb{Z}.$$

Some properties of the Fourier Series

- Time shift:

$$x(t) = s(t - t_0) \longrightarrow X_n = S_n e^{-i2\pi n F t_0}.$$

- Mean Value:

$$m_s(T_p) = \frac{1}{T_p} \int_{t_0}^{t_0+T_p} s(t) dt = S_0.$$

- Parseval's theorem:

$$P_s = \frac{1}{T_p} \int_{t_0}^{t_0+T_p} |s(t)|^2 dt = \sum_{n=-\infty}^{+\infty} |S_n|^2.$$

Examples

- A real sinusoid:

$$s(t) = A_0 \cos(2\pi f_0 t + \varphi_0) \quad \longrightarrow \quad s(t) = \frac{1}{2} A_0 e^{i\varphi_0} e^{i2\pi F t} + \frac{1}{2} A_0 e^{-i\varphi_0} e^{-i2\pi F t}.$$

$$S_1 = \frac{1}{2} A_0 e^{i\varphi_0}, \quad S_{-1} = \frac{1}{2} A_0 e^{-i\varphi_0}, \quad S_n = 0 \quad \text{for } |n| \neq 1.$$

- A square wave:

$$s(t) = \sum_{n=-\infty}^{+\infty} A_0 \operatorname{rect}\left(\frac{t - nT_p}{dT_p}\right) = A_0 \operatorname{rep}_{T_p} \operatorname{rect}\left(\frac{t}{dT_p}\right), \quad 0 < d \leq 1$$

$$S_n = \frac{1}{T_p} \int_{-\frac{1}{2}dT_p}^{\frac{1}{2}dT_p} A_0 e^{-i2\pi n F t} dt.$$

$$S_n = S_0 \operatorname{sinc}(nd), \quad S_0 = A_0 d.$$

The Fourier Transform

- An aperiodic signal $s(t)$, $t \in \mathbb{R}$, can be represented by the *Fourier integral*:

$$s(t) = \int_{-\infty}^{+\infty} S(f) e^{i2\pi ft} df, \quad t \in \mathbb{R},$$

- *And*

$$S(f) = \int_{-\infty}^{+\infty} s(t) e^{-i2\pi ft} dt, \quad f \in \mathbb{R}.$$

$$s(t) \xrightarrow{\mathcal{F}} S(f), \quad S(f) \xrightarrow{\mathcal{F}^{-1}} s(t).$$

Interpretation

- In the Fourier series, a *continuous-time* periodic signal is represented by a *discrete frequency* function

$$S_n = S(nF).$$

- In the Fourier Transform, this is no more true and we find a symmetry between the time domain and the frequency domain, which are both continuous.
- In the Fourier Transform a signal is represented as the sum of infinitely many exponential functions of the form

$$[S(f) df] e^{i2\pi ft}, \quad f \in \mathbb{R}$$

Properties

- For real signals the Fourier Transform has the Hermitian Symmetry:

$$S(-f) = S^*(f),$$

- Time shift:

$$s(t - t_0) \xrightarrow{\mathcal{F}} S(f)e^{-i2\pi f t_0}.$$

- Frequency shift:

$$S(f - f_0) \xrightarrow{\mathcal{F}^{-1}} s(t)e^{i2\pi f_0 t}.$$

- Convolution:

$$x * y(t) \xrightarrow{\mathcal{F}} X(f)Y(f).$$

Examples

- Rectangular pulse and sinc function

$$S(f) = A_0 \int_{-\frac{1}{2}D}^{\frac{1}{2}D} e^{-i2\pi ft} dt = \frac{A_0}{-i2\pi f} (e^{-i\pi f D} - e^{i\pi f D}) = A_0 \frac{\sin \pi f D}{\pi f}.$$

$$A_0 \operatorname{rect}(t/D) \xrightarrow{\mathcal{F}} A_0 D \operatorname{sinc}(f D).$$

$$S(t) = A_0 D \operatorname{sinc}(t D) \xrightarrow{\mathcal{F}} s(-f) = A_0 \operatorname{rect}(-f/D),$$

- Impulses

$$S(f) = \int_{-\infty}^{+\infty} \delta(t - t_0) e^{-i2\pi ft} dt = e^{-i2\pi f t_0}.$$

$$\delta(t - t_0) \xrightarrow{\mathcal{F}} e^{-i2\pi f t_0}$$

Examples

- Periodic signals

$$\cos 2\pi Ft = \frac{1}{2}(e^{i2\pi Ft} + e^{-i2\pi Ft}) \xrightarrow{\mathcal{F}} \frac{1}{2}[\delta(f - F) + \delta(f + F)],$$

$$\sin 2\pi Ft = \frac{1}{2i}(e^{i2\pi Ft} - e^{-i2\pi Ft}) \xrightarrow{\mathcal{F}} \frac{1}{2i}[\delta(f - F) - \delta(f + F)].$$

$$s(t) = \sum_{n=-\infty}^{+\infty} S_n e^{i2\pi nFt} \xrightarrow{\mathcal{F}} \sum_{n=-\infty}^{+\infty} S_n \delta(f - nF).$$

- Signum signal

$$\text{sgn}(t) \xrightarrow{\mathcal{F}} \frac{1}{i\pi f}.$$

- Step signal

$$1(t) = \frac{1}{2} + \frac{1}{2} \text{sgn}(t) \xrightarrow{\mathcal{F}} \frac{1}{2} \delta(f) + \frac{1}{i2\pi f}.$$